Troubleshooting Messages that Display When Modifying a Deck's Floor Finish or Floor Structure

Reference Number: **KB-01121** Last Modified: **July 15, 2024**

The information in this article applies to:



QUESTION

When I adjust the flooring components of a Deck room, I receive one of the following messages:

- "#272005536 The Floor Structure Definition for a Deck room should have a planking layer and a joist layer. In order for joists and planks to generate, the joist layer must be specified as Framing."
- "#272005536 The deck floor structure typically has two layers: a deck planking layer and a joist layer with a framing material. Planking should not be in the floor finish."
- "#272032900 The planking and joists for Deck rooms must be specified in the room's Floor Structure Definition. Deck rooms do not typically have a Floor Finish."

How do I resolve this?

ANSWER

One of theses messages will display if you add a Floor Finish layer or remove the needed framing characteristics from the Floor Structure of a Deck room.

Unlike other room types that use a Floor Finish material that spans the entire floor, deck planking is part of the Floor Structure and does not require a Floor Finish layer. Although a Floor Finish layer can still be added, it should instead be used to apply some other type of covering laid over the deck planking, such as artificial turf or deck carpet.

If you have not altered the Floor Finish, but you are receiving one of the messages above, then you may have adjusted the Floor Structure of a Deck room in such a way that the joist layer is no longer specified as Framing (or is no longer using a Framing material in legacy versions).

To add a Floor Finish layer to a Deck room*

*Applies to Chief Architect Premier only.

- 1. Click inside the Deck room to select it, then click the **Open Object** edit button.
- 2. On the STRUCTURE panel of the **Room Specification** dialog that opens, click the **Edit** button to the right of Floor Finish.
- 3. In the **Floor Finish Definition** dialog that displays, click the **Insert Above** or **Insert Below** button to add a new layer to the floor finish.

| ↓ Floor Finish Definition × | | | | | | | | | | | |
|-----------------------------|--------------------|---------|------------|---------|-----------|------------------|-------------|--|--|--|--|
| Material L | Layers | | 🔬 - 🔀 🚯 🖪 | | | | | | | | |
| Layer # | Material | Pattern | Texture | Fill | Thickness | Insert Above | | | | | |
| 1 | Insulation Air Gap | | No Texture | | 2" | Insert Below | | | | | |
| | 45 | | | | | Move Up | | | | | |
| | | | | | | Move Down | | | | | |
| | | | | | | Delete | | | | | |
| | | | | | | Total Thickness: | | | | | |
| | | | | | | 2" | | | | | |
| Structure | | | | | | | | | | | |
| | | | | | | | | | | | |
| | Туре: | Lur | mber | \sim | | | | | | | |
| | Spacing: | 0" | | On Cent | ter | | | | | | |
| | Width: | 0" | | | | | | | | | |
| Auto Detail as Insulation | | | | | | | | | | | |
| | Air Gap | | | | | | | | | | |
| Number | r Style | | | | | ОК | Cancel Help | | | | |

- With the new layer added and selected, click on the current Material to open the **Select Material** dialog, in which you can select your desired covering material (e.g. turf, deck carpet, etc.).
- Select the Thickness value and enter a thickness of your choosing.
- For more information on the other settings located here, please refer to your program's documentation by selecting the **Help** button at the bottom of the dialog.
- Once all desired changes have been made, click **OK**.
- 4. When the Floor Finish is set up correctly, click **OK**. You will receive one of the messages listed at the beginning of this article. Click **OK** on this message, then click **OK** again to close the dialog altogether.

5. Take a **Camera ()** view to see the results.



To specify a Deck room's joist layer as framing

- 1. Click inside the Deck room to select it, then click the **Open Object** room to select it, then click the **Open Object**
- 2. On the STRUCTURE panel of the **Room Specification** dialog that opens, under the Floor section, click the **Edit** button at the bottom.
- 3. In the **Floor Structure Definition** dialog, two layers should be listed: Layer #1 should represent the deck planks and Layer #2 should represent the deck joists.

| → Floor Structure Definition × | | | | | | | | | | |
|--------------------------------|------------------------------|---------|---------|-------------|-----------|------------------|-------------|--|--|--|
| Material I | Layers | | | | | | | | | |
| Layer # | Material | Pattern | Texture | Fill | Thickness | Insert Above | | | | |
| 1 | Redwood | | | 1010 | 1 1/8" | Insert Below | | | | |
| 2 | CA-B Pressure Treated Lumber | | 御書 | | 7 1/4" | Move Up | | | | |
| | | | | | | Move Down | | | | |
| | | | | | | Delete | | | | |
| | | | | | | Total Thickness: | | | | |
| | | | | | | 8 3/8" | | | | |
| Energy Va | | | | | | | | | | |
| C | Cavity R-Value: 0. | 0 | | | | | | | | |
| C | Continuous R-Value: 0. | 0 | | | | | | | | |
| Structure | | | | | | | | | | |
| 2 | Framing | | | | | | | | | |
| | Туре: Lu | umber | \sim | | | | | | | |
| | Auto Detail as Insulation | | | | | | | | | |
| | Air Gap | | | | | | | | | |
| Number | r Style | | | | | ОК | Cancel Help | | | |

- Select Layer #1 and specify an appropriate deck plank material, such as wood or composite.
- Select Layer #2 and specify an appropriate deck joist material, such as pressure treated lumber.

• With Layer #2 still selected, check the **Framing** box located under the Structure section, if its not already checked. This must be checked for deck joists to generate correctly.

In legacy versions, a Framing box was not available for Floor Structure layers. Instead, one of the specially designed Framing materials must be set for the joist layer.

- For more information on the other settings located here, please refer to your program's documentation by selecting the **Help** button at the bottom of the dialog.
- Once all desired changes have been made, click **OK**.
- 4. Once the Floor Structure is set up correctly, click **OK**. If you continue to receive one of the messages listed at the beginning of this article, please repeat Step 3.

If the deck joist layer is set as Framing and the message persists each time you close the Floor Structure Definition dialog, please send your plan file to Chief Architect Technical Support using the <u>Technical Support</u> <u>Center (https://support.chiefarchitect.com/home)</u>.

Related Articles

Customizing Deck Planking and Framing Automatically (https://www.chiefarchitect.com/support/article/KB-00794/customizing-deck-planking-and-framing-automatically.html)

Manually Modifying Deck Framing (https://www.chiefarchitect.com/support/article/KB-01245/manuallymodifying-deck-framing.html)

Using the Technical Support Center (/support/article/KB-00717/using-the-technical-support-center.html)

© 2003–2024 Chief Architect, Inc. All rights reserved // Terms of Use (https://www.chiefarchitect.com/company/terms.html) // Privacy Policy

(https://www.chiefarchitect.com/company/privacy.html)